**Address:**
21750 8th St East
Sonoma, CA 95476
**Contact:**
707-939-2244
support@griggsracing.com

# CCM BSB-U Offset Rack Bushings, Urethane

Completely read instructions before beginning.

**1)** Unbolt steering rack and pull forward.

**2)** On '86 and newer cars there are two sleeves pressed into the frame that protrudes through the rack mountings. These sleeves must be shortened so that only 1/8" is all that protrudes from frame. Mark the sleeves appropriately and remove (squeeze and pull with pliers). Cut squarely where marked and rein stall. It is important that this be done accurately to prevent over or under compression of new bushing, which could cause rack to move left or right while in use.

**3)** Remove the stock rubber mount bushings from rack.

**4)** Insert new offset bushings with the hole in the downward position, with the shoulder of bushing to the front. This should raise the rack approximately 3/8"

**5)** Reinstall rack and torque mounting bolts to 45-55ft. lbs.